


Lock Screen.

The Lock Screen is the first screen you see every time you turn on your phone, even before you get inside it. It shows you the most basic information at a glance, without needing to unlock it.

Notifications
if you have new messages, calls, or notifications from apps, they appear as small boxes on the screen.

Flashlight
to turn on your phone's flash.




Camera
for quick access.

Lock Screen.

Lock Screen.

Time

Date



Icons that show **your device status**, such as how much battery you have or whether you are connected to Wi-Fi.

Lock Screen.

How to unlock your phone.



1. Wake up the screen

Briefly press the side button (power button) to turn on the screen.

2. Unlock your phone

To unlock your phone, swipe up starting from the small white line visible at the bottom of the screen. If your device has a fingerprint-scanner button, place your finger there.

3. Confirm your identity

If a numeric keypad appears, enter your personal code — the code you set when you first set up your phone, or the one given to you by the person who helped you set it up.